

## PERC Series

PRODUCT	Container Ft.	Ship to	Pallets	Panels	POWER
72-Cell 420W	53'	Most States	28	728	305.76kW
		California	25	650	273.00kW
66-Cell 380W	53'	Most States	30	780	296.40kW
		California	26	676	256.88kW
60-Cell 345W	53'	Most States	34	884	304.98kW
		California	28	728	251.16kW

## America's Module Company™

[www.missionsolar.com](http://www.missionsolar.com)

PALLET DIMENSIONS & WEIGHT			
26 Panels/Pallet			
	72-Cell	66-Cell	60-Cell
Product	MSExxxSX6W, MSExxxSX6Z	MSExxxSX5R	MSExxxSX5T, MSExxxSX5K
Weight	1,450 lbs.	1,356 lbs.	1,263 lbs.
Height	47.56 in.	47.56 in.	47.56 in.
Length	83.75 in.	77 in.	70.25 in.
Width	46 in.	46 in.	46 in.



COMPLETE PALLET

EXPLODED PALLET

### STORAGE TRANSPORT INSTRUCTIONS



Use caution when moving modules around warehouse or job site. Do not exceed rated load capacity of forklift. Only transport a double-stacked pallet if it is well aligned. Do not collide with other objects while transporting modules. Only use fork lifts with long forks (at least 72" or 6') to move the pallets.



Fragile! Modules should be handled carefully. Do not place modules roughly on hard surface or on their corners. Do not drag modules over each other when unstacking.



The package must always be transported, handled and stored in such a way that the arrows always point upwards.



Do not step or stand on modules. Do not place any objects on modules.



The cardboard sleeve and package materials are recyclable.



Do not use forklift truck on glass side.



Package and modules should be protected from excessive moisture (rain, snow, etc.) and must accordingly be stored under cover. If package and modules cannot be stored in warehouses or sheds, they must be carefully covered with tarpaulins.



Never stack more than 2 pallets high. Double-stacked pallets need to have anti-slip pads between pallets.



Use two people when unpacking modules from pallet. When handling modules always use both hands and safety gloves.